


**BEFORE YOU BEGIN**

Read these instructions completely and carefully.  
Save these instructions for future use.

**WARNING**


**Risk of electrical shock.** Disconnect power before servicing or installing luminaire.

**WARNING**

**Risk of injury or damage.** Luminaire will fall if not installed properly. Follow installation instructions.

**WARNING**

**Risk of injury.** Wear safety glasses and gloves during installation and servicing.

**PRODUCT DIMENSIONS: AV08/12 & AV16/20/24**

**Important Notice**


These instructions are not intended to cover all details or variations in the products nor do these instructions provide for every possible contingency concerning the installation, operations, or maintenance of the luminaire. Should additional information be required, contact Greenstar Products, Inc.

The contents of this manual shall not become a part of or modify any prior or existing agreement, commitment, or relationship. The sales contract contains the entire obligation of Greenstar Products, Inc. Greenstar Products, Inc.'s standard limited warranty is the sole warranty obligation of Greenstar Products, Inc. and any statements contained herein do not create new warranties or modify the existing warranty.

Any electrical or mechanical modifications to the luminaire without the prior written consent of Greenstar Products, Inc. may void all warranties or other safety certifications. Unauthorized modifications may also result in safety hazards or damage to the luminaire. Misuse of the luminaire could result in injury and equipment damage. In no event will Greenstar Products, Inc. be responsible or liable for direct, indirect, special, or consequential damage or injury that may result from the misuse of the luminaire.

**WARNING**

**Risk of damaging mounting hardware.** Hand tighten nuts evenly before using wrench. Optimal torque value 4.5 ft.-lbs. Do not exceed 7 ft.-lbs. of torque. Do not use uncontrolled pneumatic or hydraulic tools to tighten.



\*\* Failure to follow proper mounting sequence instructions may result in jammed nuts or sheared studs \*\*\*

